


ZOOM

SIZED FOR PRINT

REMOVAL




ZOOM

SIZED FOR PRINT

1. REMOVE STABILIZER BAR LINKS

- a. Remove the 2 nuts and stabilizer bar link. Torque: **44 Nm (449 kgf.cm, 32 ft. lbs.)** **HINT:** If the ball joint turns together with the nut, use a hexagon (5 mm) wrench to hold the stud.
- b. Employ the same manner described above to the other side.

2. REMOVE FRONT SUSPENSION MEMBER WITH LOWER SUSPENSION ARM



ZOOM


SIZED FOR PRINT

3. REMOVE STABILIZER BAR

- a. Remove the 2 bolts, bracket and bushing. Torque: **19 Nm (194 kgf.cm, 14 ft. lbs.)** **HINT:** At the time of installation, please refer to the following items.
 - Install the bushing so that the cutout will face to the rear.
 - Install the bushing to the outside of the paint line on the stabilizer bar.
- b. Employ the same manner described above to the other side.
- c. Remove the stabilizer bar.

INSPECTION

INSPECT STABILIZER BAR LINK BALL JOINT FOR ROTATION CONDITION



ZOOM

SIZED FOR PRINT

- a. As shown in the illustration, flip the ball joint stud back and forth 5 times, before installing the nut.
- b. Using a torque wrench, turn the nut continuously at a rate of 2 - 4 seconds per 1 turn and take the torque reading on the 5th turn. Turning torque: **0.05 - 1.0 Nm (0.5 - 10 kgf.cm, 0.4 - 8.7 inch lbs.)**

INSTALLATION

Installation is in the reverse order of removal.

HINT: After installation, check the front [wheel](#) alignment.